



# + USER GUIDE

## EVOMAX

30 40 60 80 100 120 150  
30P 40P 60P 80P

When replacing any part on this appliance, use only spare parts that you can be assured conform to the safety and performance specification that we require. Do not use reconditioned or copy parts that have not been clearly authorised by Ideal.

**For the very latest copy of literature for specification and maintenance practices visit our website [www.idealcommercialboilers.com](http://www.idealcommercialboilers.com) where you can download the relevant information in PDF format.**


## EVOMAX

**30, 40, 60, 80, 100, 120, & 150  
30P, 40P, 60P & 80P**

Natural Gas & LPG

PI No. 86 CL 166

Destination Countries: GB, IE



### Introduction

The **EVOMAX** is a wall mounted, room sealed, super efficient condensing boiler featuring full sequence automatic spark ignition and fan assisted combustion.

Due to the very high efficiency, condensate is produced from the flue gases and this is drained to a suitable disposal point through the plastic waste pipe at the bottom of the boiler. A condensate 'plume' will also often be visible at the flue terminal.

### Safety

#### Current Gas Safety (Installation & Use) Regulations or rules in force.

In your own interest, and that of safety, it is the law that this boiler must be installed and maintained by a Gas Safe Registered Engineer or in IE a competent person, in accordance with the above regulations.

The appliance should be serviced at least once a year by a Gas Safe Registered Engineer or in IE a competent person.

*It is essential that the instructions in this booklet are strictly followed, for safe and economical operation of the boiler.*

### Electricity Supply

The appliance must be earthed.

Supply 230 V - 50 Hz. The fusing should be 3A (5A for 100).

This appliance is intended to be connected to the supply via a double-pole switch, having a 3mm contact separation in both poles, serving only the boiler and system controls. Alternatively, a 3-pin UNSWITCHED socket may be used.

### Important Notes

- This appliance must not be operated without the casing correctly fitted and forming an adequate seal.
- If the boiler is installed in a compartment then the compartment **MUST NOT** be used for storage purposes.
- Do not store objects around or on the boiler, and keep access clear at all times.
- Do not obstruct ventilation ducts, grilles or openings in the boiler room, room space or compartment that the appliance is installed in, or the passage of combustion and ventilation to the boiler.
- Do not turn off the boiler if it is to be left unattended in frosty weather.
- If it is known or suspected that a fault exists on the boiler then it **MUST NOT BE USED** until the fault has been corrected by a Gas Safe Registered Engineer or in IE a competent person.
- Flammable materials must not be placed in close proximity to the appliance. Materials giving off flammable vapours must not be stored in the same room as the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

In cases of repeated or continuous shutdown a Gas Safe Registered Engineer or in IE a competent person should be called to investigate and rectify the condition causing this and carry out an operational test after each intervention on the device. Only the manufacturers original parts should be used for replacement.

### Minimum Clearances

Clearances of **300mm (12")** below, **25mm (1")** at the sides and **450mm (17 3/4")** at the front of the boiler casing must be allowed for servicing.

### To light the boiler (Refer to Frame 1)

1. CHECK THAT THE ELECTRICITY SUPPLY TO THE BOILER IS OFF.
2. Set the boiler to standby.
3. Switch on the electricity supply to the boiler and check that all external controls, e.g. programmer, room thermostat, etc are on. Allow the boiler to carry out a self check.
4. Set the boiler to winter.


The boiler will commence the ignition sequence, supplying heat to the system when required.

All **Gas Safe Registered Engineers** carry a Gas Safe Register ID card, and have a registration number.

Both should be recorded in your Log Book. You can check your installer by calling Gas Safe Register direct on 0800 4085500.

**CAUTION. To avoid the possibility of injury during the installation, servicing or cleaning of this appliance care should be taken when handling edges of sheet steel components.**

# 1 BOILER CONTROLS / DISPLAY



## Standby Mode

If the boiler has been switched to Standby Mode the following screen will be displayed  
No Boiler operation will take place with this setting. See Frame 38 to change to Summer or Winter setting

Standby Mode
For Central Heating select Winter Mode
For Hot Water select Summer or Winter

## Summer Mode

If the boiler has been switched to Summer Mode a screen similar to the following will be displayed (line 5 may vary depending on setup)  
Domestic Hot Water operation will take place with this setting but Central Heating will not.  
See Frame 38 to enable Central Heating by changing to Winter setting

Summer Mode
For Central Heating select Winter Mode
No Hot Water Demand Switched Live
Off

## Winter Mode

If there is no current Heat Demand a screen similar to the following will be displayed (line 5 may vary depending on setup)  
Line 5 indicates "Switched Live" or "OpenTherm" or "0-10V" depending on which controls are connected to the boiler

Winter Mode
No Central Heating Demand
No Hot Water Demand Switched Live
Off

## Domestic Hot Water Mode (DHW Thermostat)

If there is an ongoing Domestic Hot Water Demand using a DHW Thermostat screens similar to the following will be displayed  
Line 2 indicates whether Switched Live or OpenTherm is controlling the boiler  
Line 3 indicates the current operating State (Pre-Purge or Ignition or Burner On or Pump Overrun)  
Burner Power and Flow Temperature will vary as the boiler operates

Hot Water
DHW Switched Live On
Burner On
DHW Thermostat
Flow Temp
80°C



Hot Water
Burner Power
100%
Burner On
DHW Thermostat
Flow Temp
80°C

## Central Heating Mode

If there is an ongoing Central Heating Demand screens similar to the following will be displayed  
Line 2 indicates whether Switched Live or OpenTherm is controlling the boiler  
Line 3 indicates the current operating State (Pre-Purge or Ignition or Burner On or Pump Overrun)  
Outside temperature will only be shown if an outside sensor is connected to the boiler  
Burner Power and Flow Temp will vary as the boiler operates  
See Frame 38 for adjusting Flow Setpoint

Central Heating
CH Switched Live On
Burner On
Flow Setpoint
80°C
Flow Temp
80°C



Central Heating
Burner Power
100%
Outside Temp'
10°C
Flow Setpoint
80°C
Flow Temp
80°C

## Boiler Frost Protection Mode

If the boiler flow temperature drops below 5°C screens similar to the following will be displayed  
Line 3 indicates the current operating State (Pre-Purge or Ignition or Burner On or Pump Overrun)  
Outside temperature will only be shown if an outside sensor is connected to the boiler  
Burner Power and Flow Temp will vary as the boiler operates

Boiler Frost Protect
Burner Power
100%
Burner On
Frost Setpoint
5°C
Flow Temp
80°C



Boiler Frost Protect
Burner Power
100%
Outside Temp'
10°C
Frost Setpoint
5°C
Flow Temp
80°C

## 2 EVOMAX USER INTERFACE - BASIC OPERATING INSTRUCTIONS

### SETTING FLOW TEMPERATURE

Press SELECT and a screen similar to the following will be displayed  
The kW output number in the 1st line will vary depending the maximum output of the boiler

<u>Ideal Evomax 80kW</u>
<b>Normal Operation</b>
Set Flow Temp'
Set DHW Temp'

Rotate the KNOB clockwise until a screen similar to the following is displayed

<u>Ideal Evomax 80kW</u>
<u>Normal Operation</u>
<b>Set Flow Temp'</b>
Set DHW Temp'
Set Off/Sum/Win

Press SELECT and a screen similar to the following will be displayed

<u>Set Flow Temp'</u>
80°C

Press + and - to change to the required setting and then press ENTER to store

Rotate the KNOB anti-clockwise until Normal Operation is highlighted again and press SELECT to return to normal operation

### SETTING SUMMER, WINTER AND STANDBY OPERATION

Note that Standby Mode will disable Domestic Hot Water and Central Heating, Summer Mode will disable Central Heating

Press SELECT and a screen similar to the following will be displayed  
The kW output number in the 1st line will vary depending the maximum output of the boiler

<u>Ideal Evomax 80kW</u>
<b>Normal Operation</b>
Set Flow Temp'
Set DHW Temp'

Rotate KNOB clockwise until a screen similar to following is displayed

<u>Ideal Evomax 80kW</u>
Set DHW Temp'
<b>Set Off/Sum/Win</b>
Out' Sensor Slope
Normal Operation

Press SELECT and a screen similar to the following will be displayed

<u>Set Off/Sum/Win</u>
Standby
<b>Summer</b>
Winter
Press - for more

Press + and - to change to required setting, press ENTER to store

Rotate the KNOB anti-clockwise until Normal Operation is highlighted again and press SELECT to return to normal operation

## ***To shut Down the Boiler***

### **1. For short periods**

Set the external controls to OFF. Wait 4 minutes and then isolate the mains supply to the boiler.

### **2. For longer periods**

Set the external controls to OFF. Switch the electricity supply to OFF. For longer periods the entire system should be drained, including the domestic hot water supply.

## ***To Relight the Boiler***

Refill the system if it has been drained, taking care to ensure no air is in the boiler or system.

Repeat the procedure detailed in 'To light the boiler'.

## ***Frost Protection***

The EVOMAX boiler has built into its control system the facility to protect the boiler only against freezing.

### **Note.**

This may not protect remote parts of the system, in which case a separate frost thermostat should be fitted.

## ***Boiler Overheat Thermostat***

Boiler overheating is detected by electrical sensors connected to the boiler control module. If the boiler overheats it will shut down and the display will show Overheat Lockout. Press the reset button and the boiler will relight. If the fault recurs turn off the boiler and consult a Gas Safe Registered Engineer or in IE a competent person.

## ***Condensate Drain***

This appliance is fitted with a siphonic condensate trap system that reduces the risk of the appliance condensate from freezing. However should the condensate pipe to this appliance freeze, please follow these instructions:

- a. If you do not feel competent to carry out the defrosting instructions below please call your local Gas Safe Registered installer for assistance.
- b. If you do feel competent to carry out the following instructions please do so with care when handling hot utensils. Do not attempt to thaw pipework above ground level.

If this appliance develops a blockage in its condensate pipe, its condensate will build up to a point where it will make a gurgling noise prior to locking out displaying "Ignition Lockout" on the display. If the appliance is reset it will make a gurgling noise prior to it locking out displaying "Ignition Lockout" on the display.

To unblock a frozen condensate pipe;

1. Follow the routing of the plastic pipe from its exit point on the appliance, through its route to its termination point.

Locate the frozen blockage. It is likely that the pipe is frozen at the most exposed point external to the building or where there is some obstruction to flow. This could be at the open end of the pipe, at a bend or elbow, or where there is a dip in the pipe in which condensate can collect. The location of the blockage should be identified as closely as possible before taking further action.

2. Apply a hot water bottle, microwaveable heat pack or a warm damp cloth to the frozen blockage area. Several applications may have to be made before it fully defrosts. Warm water can also be poured onto the pipe from a watering can or similar. DO NOT use boiling water.
3. Caution when using warm water as this may freeze and cause other localised hazards.
4. Once the blockage is removed and the condensate can flow freely, reset the appliance. (Refer to "To Light the boiler")
5. If the appliance fails to ignite, call your Gas Safe Registered engineer.

### **Preventative solutions**

During cold weather, set the boiler stat to maximum, (Must return to original setting once cold spell is over)

Place the heating on continuous and turn the room stat down to 15°C overnight or when unoccupied. (Return to normal after cold spell).

## ***Escape of Gas***

Should a gas leak or fault be suspected contact your local gas supplier without delay.

Do NOT search for gas leaks with a naked flame.

## ***Cleaning***

For normal cleaning simply dust with a dry cloth.

To remove stubborn marks and stains use a damp cloth and mild detergent.

DO NOT use abrasive cleaning materials.

