



USER GUIDE

IMAX XTRA EL 715-1240kW

When replacing any part on this appliance, use only spare parts that you can be assured conform to the safety and performance specification that we require. Do not use reconditioned or copy parts that have not been clearly authorised by Ideal.


For the very latest copy of literature for specification and maintenance practices visit our website www.idealcommercialboilers.com where you can download the relevant information in PDF format.

IMAX XTRA EL

715, 790, 940, 1090, 1240

Natural Gas only

Destination Countries: GB, IE



Introduction

The **IMAX XTRA EL** is a floor mounted, super efficient condensing boiler featuring full sequence automatic spark ignition and fan assisted combustion appliance.

Due to the very high efficiency, condensate is produced from the flue gases and this is drained to a suitable disposal point through the condense traps at the rear of the boiler. A condensate 'plume' will also often be visible at the flue terminal.

Safety

Current Gas Safety (Installation & Use) Regulations or rules in force.

In your own interest, and that of safety, it is the law that this boiler must be installed and maintained by a Gas Safe Registered Engineer or in IE a competent person, in accordance with the above regulations.

The appliance should be serviced at least once a year by a Gas Safe Registered Engineer or in IE a competent person.

It is essential that the instructions in this booklet are strictly followed, for safe and economical operation of the boiler.

Electricity Supply

The appliance must be earthed.

Supply 230 V - 50 Hz. The Master and Slave Modules each have their own 230V AC supply, each should be fused at 7A.

This appliance is intended to be connected to the supply via a double-pole switch, having a 3mm contact separation in both poles, serving only the boiler and system controls.

Important Notes

- If the boiler is installed in a compartment then the compartment **MUST NOT** be used for storage purposes.
- Do not store objects around or on the boiler, and keep access clear at all times.
- Do not obstruct ventilation ducts, grilles or openings in the boiler room, room space or compartment that the appliance is installed in, or the passage of combustion and ventilation to the boiler.
- Do not turn off the boiler if it is to be left unattended in frosty weather.
- If it is known or suspected that a fault exists on the boiler then it **MUST NOT BE USED** until the fault has been corrected by a Gas Safe Registered Engineer or in IE a competent person.
- Flammable materials must not be placed in close proximity to the appliance. Materials giving off flammable vapours must not be stored in the same room as the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

In cases of repeated or continuous shutdown a Gas Safe Registered Engineer or in IE a competent person should be called to investigate and rectify the condition causing this and carry out an operational test after each intervention on the device. Only the manufacturer's original parts should be used for replacement.

Minimum Clearances

Front 700mm	Rear 1000mm
LHS 700mm	RHS 700mm

To light the boiler (Refer to Frame 1)


1. CHECK THAT THE ELECTRICITY SUPPLY TO THE BOILER IS OFF.
2. Set the boiler to standby.
3. Switch on the electricity supply to the boiler and check that all external controls, e.g. programmer, room thermostat, etc are on. Allow the boiler to carry out a self check.
4. Set the boiler to winter.

The boiler will commence the ignition sequence, supplying heat to the system when required.

All Gas Safe Register installers carry a Gas Safe Register ID card, and have a registration number. Both should be recorded in the Commissioning Report. You can check your installer by calling Gas Safe Register direct on 0800 4085500.

CAUTION. To avoid the possibility of injury during the installation, servicing or cleaning of this appliance care should be taken when handling edges of sheet steel components.

1 BOILER CONTROLS / DISPLAY



Standby Mode

If the Module has been switched to Standby Mode the following screen will be displayed
No Module operation will take place with this setting.

Standby Mode
For Central Heating select Winter Mode
For Hot Water select Summer or Winter

Summer Mode - Master Module Only

If the boiler has been switched to Summer Mode a screen similar to the following will be displayed.
Domestic Hot Water operation will take place with this setting but Central Heating will not.

Summer Mode
For Central Heating select Winter Mode
No Hot Water Demand
OpenTherm Connected

Winter Mode

If there is no current Heat Demand a screen similar to the following will be displayed, Domestic Hot Water will only show on the Master Module User Interface.

Winter Mode
No Central Heating Demand
No Hot Water Demand
OpenTherm Connected

Central Heating Mode

If there is an ongoing Central Heating Demand screens similar to the following will be displayed.

Line 2 indicates whether Switched Live or OpenTherm is controlling the boiler.

Line 3 indicates the current operating State (Pre-Purge or Ignition or Burner On or Pump Overrun).

Outside temperature will only be shown if an outside sensor is connected to the boiler.

Burner Power and Flow Temp will vary as the boiler operates

MASTER MODULE

Central Heating
OpenTherm Mode
Burner On
Flow Setpoint 80°C
Flow Temp 80°C

Central Heating
Burner Power 100%
Outside Temp' 10°C
Flow Setpoint 80°C
Flow Temp 80°C

SLAVE MODULE

Central Heating
OpenTherm Mode
Burner On
Burner Setpoint 100%
Flow Temp 80°C

Central Heating
Burner Power 100%
Outside Temp' 10°C
Flow Setpoint 80°C
Flow Temp 80°C

Boiler Frost Protection Mode

If the boiler flow temperature drops below 5°C screens similar to the following will be displayed.

Line 3 indicates the current operating State (Pre-Purge or Ignition or Burner On or Pump Overrun).

Outside temperature will only be shown if an outside sensor is connected to the boiler.

Burner Power and Flow Temp will vary as the boiler operates.

Boiler Frost Protect
Burner Power 100%
Burner On
Frost Setpoint 5°C
Flow Temp 80°C

Boiler Frost Protect
Burner Power 100%
Outside Temp' 10°C
Frost Setpoint 5°C
Flow Temp 80°C

2 USER INTERFACE - BASIC OPERATING INSTRUCTIONS

SETTING SUMMER, WINTER AND STANDBY OPERATION

Note that Standby Mode will disable Domestic Hot Water and Central Heating, Summer Mode will disable Central Heating.

Press SELECT and a screen similar to the following will be displayed

The kW output number in the 1st line will vary depending on the maximum output of the boiler.

MASTER MODULE	Ideal imax XLM 1240 kW
	Normal Operation
	Set Off/Sum/Win
	State of Inputs

SLAVE MODULE	Ideal imax XLS 1240 kW
	Normal Operation
	Set Off/Win
	State of Inputs

Rotate KNOB clockwise until a screen similar to following is displayed

MASTER MODULE	Ideal imax XLM 1240 kW
	Set DHW Temp'
	Set Off/Sum/Win
	State of Inputs
	State of Outputs

SLAVE MODULE	Ideal imax XLS 1240 kW
	Set DHW Temp'
	Set Off/Win
	State of Inputs
	State of Outputs

Press SELECT and a screen similar to the following will be displayed

MASTER MODULE	Set Off/Sum/Win
	Standby
	Summer
	Winter
	Press - for more

SLAVE MODULE	Set Off/Win
	Standby
	Winter
	Minimum
	Press - for more

Press + and - to change to required setting, press ENTER to store.

Rotate the KNOB anti-clockwise until Normal Operation is highlighted again and press SELECT to return to normal operation.

To Shut Down the Boiler

1. For short periods

Set the external controls to OFF. Wait 4 minutes and then isolate the mains supply to the boiler.

2. For longer periods

Set the external controls to OFF. Switch the electricity supply to OFF. For longer periods the entire system should be drained, including the domestic hot water supply.

To Relight the Boiler

Refill the system if it has been drained, taking care to ensure no air is in the boiler or system.

Repeat the procedure detailed in 'To light the boiler'.

Frost Protection

The IMAX XTRA EL boiler has built into its control system the facility to protect the boiler only against freezing.

Note.

This may not protect remote parts of the system, in which case a separate frost thermostat should be fitted.

Boiler Overheat Thermostat

Boiler overheating is detected by electrical sensors connected to the boiler control module. If the boiler overheats it will shut down and the display will show Overheat Lockout. Press the reset button and the boiler will relight. If the fault recurs turn off the boiler and consult a Gas Safe Registered Engineer or in IE a competent person.

Condensate Drain

This appliance is fitted with a siphonic condensate trap system that reduces the risk of the appliance condensate from freezing. However should the condensate pipe to this appliance freeze, please follow these instructions:

- a. If you do not feel competent to carry out the defrosting instructions below please call your local Gas Safe Registered installer for assistance.
- b. If you do feel competent to carry out the following instructions please do so with care when handling hot utensils. Do not attempt to thaw pipework above ground level.

If this appliance develops a blockage in its condensate pipe, its condensate will build up to a point where it will make a gurgling noise prior to locking out displaying

<p><u>Low Water Pressure</u> Air Pressure/Fan Fault Check Air/Flue/Sump Fill System to 1.0 bar Check Fan/APS,WPS,FGPS</p>

on the display. If the appliance is reset it will make a gurgling noise prior to it locking out displaying the above.

To unblock a frozen condensate pipe;

1. Follow the routing of the plastic pipe from its exit point on the appliance, through its route to its termination point.

Locate the frozen blockage. It is likely that the pipe is frozen at the most exposed point external to the building or where there is some obstruction to flow. This could be at the open end of the pipe, at a bend or elbow, or where there is a dip in the pipe in which condensate can collect. The location of the blockage should be identified as closely as possible before taking further action.

2. Apply a hot water bottle, microwaveable heat pack or a warm damp cloth to the frozen blockage area. Several applications may have to be made before it fully defrosts. Warm water can also be poured onto the pipe from a watering can or similar. DO NOT use boiling water.
3. Caution when using warm water as this may freeze and cause other localised hazards.
4. Once the blockage is removed and the condensate can flow freely, reset the appliance. (Refer to "To Light the boiler")
If the condensate drain becomes blocked condensate may feed back into the air pressure switch sample pipes. If this happens the boiler may display a fault code if ignition is attempted. To resolve the problem the sample pipes must be drained and cleared of condensate before re-connecting to the air pressure switch. The boiler can then be operated.
5. If the appliance fails to ignite, call your Gas Safe Registered engineer.

Preventative solutions

During cold weather, set the boiler stat to maximum, (must return to original setting once cold spell is over).

Place the heating on continuous and turn the room stat down to 15°C overnight or when unoccupied. (Return to normal after cold spell).

Escape of Gas

Should a gas leak or fault be suspected contact your local gas supplier without delay.

Do NOT search for gas leaks with a naked flame.

Cleaning

For normal cleaning simply dust with a dry cloth.

To remove stubborn marks and stains use a damp cloth and mild detergent.

DO NOT use abrasive cleaning materials.



Ideal Boilers Ltd. pursues a policy of continuing improvement in the design and performance of its products.
The right is therefore reserved to vary specification without notice.

Ideal is a trademark of Ideal Boilers.
Registered Office

Ideal Boilers Ltd., PO Box 103, National Avenue, Kingston Upon Hull, HU5 4JN
Tel 01482 492251 Fax 01482 448858
Registration No. London 322 137

Ideal Technical Helpline: 01482 498376
www.idealcommercialboilers.com